


PARTS LIST:

	<p>ASH-E10 AST-T70 AST-T50 AST-RPR03 AST-TU06 AST-RP12</p>	<p>1 Set 1 Set 1 Set 4 Pc 4 Pc 4 Pc 4 Pc 4 Pc 4 Pc</p>	<p>Tubes (top & bottom) Side plates (left & right) Chrome/black plastic caps Vinyl gaskets 1/2" x 1 1/4" flat bolts. 3/8" x 1 1/2" carriage bolts 3/8" lock washers 3/8" hex nuts 3/8" flat washers.</p>
---	--	--	--

INSTRUCTIONS:

- 1.- Read instructions before beginning installation.
- 2.- Assemble Grill Guard using flat bolts. Tighten bolts.
- 3.- Center Grill Guard on the front bumper.
- 4.- Mark both upper and lower hole locations through mounting tabs trough bumper. Remove Grille Guard.
- 5.- Drill four 3/8" holes
(CAUTION: ALWAYS USE EYE PROTECTION WHEN OPERATING A DRILL)
- 6.- Reposition Grille Guard on bumper and attach with supplied hardware. Tighten all bolts.
- 7.- Install the chrome / black plastic caps in the flat heat bolts to cover these bolts.
- 8.- Recheck nuts and bolts periodically.
- 9.- Keep your Grill Guard clean and waxed to prevent corrosion. Use non abrasive automotive type wax.

