









36629/36629B  
**GRILL GUARD**  
NISSAN P.U., PATHFINDER 93-98

**PARTS LIST:**

		1 set	tubes (top & bottom)
		1 set	side plates (left & right)
		1 set	chrome/black plastic caps
	ASH-E10	4 pc	vinyl gaskets
	AST-T70	4 pc	1/2" x 1 1/4" flat bolts.
	AST-T50	4 pc	3/8" x 1 1/2" carriage bolts
	AST-RPR03	4 pc	3/8" lockwashers
	AST-TU06	4 pc	3/8" hex nuts

**INSTRUCTIONS:**

- 1.- Read instructions before beginning installation.
- 2.- Assemble Grill Guard using flat bolts. Tighten bolts.
- 3.- Center Grill Guard on the front bumper.
- 4.- Mark both upper and lower hole locations through mounting tabs onto bumper. Remove Grill Guard.
- 5.- Drill four 3/8" holes  
**(CAUTION: ALWAYS USE EYE PROTECTION WHEN OPERATING A DRILL)**
- 6.- Reposition Grill Guard on bumper and attach with supplied hardware. Tighten all bolts.
- 7.- Install the chrome/black plastic caps in the flat heat bolts to cover these bolts.
- 8.- Use the chrome /black plastic female end caps and the chrome/black plastic male end caps to cover the holes of the plates.
- 9.- Recheck nuts and bolts periodically.
- 10.- Keep your Grill Guard clean and waxed to prevent corrosion. Use non abrasive automotive type wax.

Thank you for choosing Go Industries products. For additional installation assistance, please call Technical Support (800) 527-4345 or (972) 783-744