

36649/36649B
GRILL GUARD
TOYOTA TACOMA 2WD 4WD 95-97
TOYOTA 4 RUNNER 96

PARTS LIST:

		1 set	tubes (top & bottom)
		1 set	side plates (left & right)
		1 set	chrome/black plastic caps
	AST-T70	4 pc	1/2" x 1 1/4" flat bolts
	ASH-E10	4 pc	vinyl gaskets
	AST-T66	4 pc	3/8" x 1 1/4" hex bolts
	AST-RP03	4 pc	3/8" flatwashers
	AST-RPR03	4 pc	3/8" lockwashers
	AST-TU06	4 pc	3/8" hex nuts
	AST-RP08	4 pc	3/8" x 1 1/2" flatwashers

INSTRUCTIONS:

- 1.- Read instructions before beginning installation.
- 2.- Assemble Grill Guard using flat bolts. Tighten bolts.
- 3.- Center Grill Guard on the front bumper.
- 4.- Mark both upper and lower hole locations through mounting tabs onto bumper. Remove Grill Guard.
- 5.- Drill four 7/16" holes
 (CAUTION: ALWAYS USE EYE PROTECTION WHEN OPERATING A DRILL)
- 6.- Reposition Grill Guard on bumper and attach with supplied hardware. Tighten all bolts.
- 7.- Install the chrome/black plastic caps in the flat heat bolts to cover these bolts.
- 8.- Use the chrome /black plastic famele caps and the chrome/black plastic male caps to cover the holes of the plates.
- 9.- Recheck nuts and bolts periodically.
- 10.- Keep your Grill Guard clean and waxed to prevent corrosion. Use non abrasive automotive type wax.