

# Winch System Grille Guard

Installation Instructions

## **33735 & 33735B**

Chevy Silverado 1500 '07 - '13

**Some models without tow hooks, will require the plastic tow hook pocket to be trimmed for bracket clearance.**



**Diagram 1**

**Parts List:**

2 - Uprights	18 - 1/2" Flat Washers
1 - Driver Side Bracket #33736-7	14 - 1/2" Lock Washers
1 - Pass. Side Bracket #33736-8	4 - 3/8" x 1 1/2" Buttonhead Bolts
4 - Nut Plates #33736-9	8- 1/2" Nuts
2 - Grille Guard Tubes	
4 - Neoprene Washers	
4 - 1/2" x 2" Carriage Bolts	<b>*May include extra hardware.</b>
14 - 1/2" x 1 1/2" Bolts	

**Note: Completely read instructions before beginning installation!**

1. Remove the contents from the box and check for missing pieces or damage. If parts are missing or damaged, contact the original place of purchase.
2. Remove the factory tow hook and factory bolts, set aside they will not be reused. Place driver main bracket #33736-7 into frame and line up the holes in the frame. Place (1) 1/2" x 5" bolt with (1) 1/2" flat washer through the frame and into the driver main bracket and back through the frame. Place a (1) 1/2" flat washer and a (1) 1/2" nut onto the 1/2" x 5" bolt only hand tighten. Put the (1) 1/2" x 1" bolt with (1) 1/2" flat washer into the second hole on the driver main bracket only hand tighten. Repeat above procedure for the passenger main bracket #33736-8.
3. Two people are recommended for this step. The uprights will go in between the brackets. Place the one upright up to the brackets aligning the large tow hook holes in the uprights and brackets. Place (1) 1/2" flat washer onto (2) 1/2" x 2" bolts and install the bolts in the two lower round holes in the bracket and passing through the upright. Place (1) 1/2" flat washer, (1) 1/2" lock washer, and (1) 1/2" nut onto the bolts and gently snug. Do the same for both uprights.
4. Install the cross tubes with (4) 3/8" x 1" buttonhead bolts and (4) neoprene washers. Place the (4) neoprene washers in between the cross tubes to protect from damage and hand tighten.
5. If installing a winch carrier refer to carrier instructions for installation. Two of the carrier bolts will use the two upper square holes on the brackets
6. Tighten the brackets to the uprights. Tighten the cross tubes second and tighten the frame bolts last making sure the winch system grille guard remains centered on truck.

## Winch System Grille Guard

Installation Instructions

**33735 & 33735B**

Chevy Silverado 1500 '07 - '13

### Bracket #33736-8



**Passenger Main  
Bracket #33736-8**

**Diagram 2**