

Enforcement Series Grille Guard

Installation Instructions

38021 / 39021 / 40021

38022 / 39022 / 40022

Ford Interceptor Utility '16 - current

38021 / 38022



39021 / 39022



40021 / 40022



Parts List:

- 1 - Grille Guard
- 1 - Bracket (Driver) #38021-25
 (38022-5 for ecoboost)
- 1 - Bracket (Passenger) #38021-26
 (38022-6 for ecoboost)
- 2 - Flat Straps #38015-7
- 8 - 1/2" x 1 1/2" Bolts
- 16 - 1/2" Flat Washers
- 8 - 1/2" Lock Washers
- 8 - 1/2" Nuts

* May include extra hardware

****This unit does require trimming of the lower grille.****

Note: Completely read instructions before beginning installation!

1. Remove the contents from the box and check for missing pieces or damage. If parts are missing or damaged, contact the original place of purchase.
2. Remove the bumper cover and plastic bumper reinforcement.
3. The lower grille will need to be removed from the bumper cover for trimming.
4. Locate brackets #38021-25 and 38021-26 (38022-5 & 38022-6 for ecoboost equipped vehicles) as well as the straps #38015-7 at this time. Bracket #38021-25 (38022-5 for ecoboost) needs to be placed on the driver's side of the rebar by pivoting it into the position as shown in **Diagram #1**. Place (1) strap #38015-7 on the front side of the rebar and up against the bracket. Place (1) 1/2" washer onto (2) 1/2" x 1 1/2" bolts. Place the bolts with washer through the top and bottom holes in the bracket and strap, then place (1) 1/2" flat washer, (1) 1/2" lock washer and (1) 1/2" nut onto each bolt. Repeat for passenger side bracket #38021-26 (38022-6 for ecoboost) Leave bolts loose at this time.
5. The brackets need to be centered on the car and a gap of 25" needs to be spaced out measuring the outside edges of the brackets at the furthest point out from the car. you may tighten the bracket hardware at this time.
6. Place the bumper cover back on the car, with the brackets exiting through the grille opening in the bumper cover to see the approximate location where the grille will need to be trimmed.
7. Trim the grille in the appropriate place and re-install into the bumper cover, then re-install the bumper cover on the vehicle.
8. Place the Grille Guard on the brackets aligning all (4) bolt holes. Place (1) 1/2" flat washer onto each of the (4) 1/2" x 1 1/2" bolts. Place (1) bolt with washer through each of the (4) guard to brackets mounting holes. Place (1) 1/2" flat washer, (1) 1/2" lock washer and (1) 1/2" nut onto each of the (4) bolts.
9. All hardware can be tightened and checked at this time, making sure the guard remains centered on the vehicle.

Enforcement Series Grille Guard

Installation Instructions

38021 / 39021 / 40021

38022 / 39022 / 40022

Diagram 1



Example of Cutout in Lower Grille for Bracket

