GO INDUSTRIES, INC
Simply the Best Grille Guard Manufacturer in America

420 N. Grove, Richardson, TX 75081
Tele: (800) 527 - 4345 Fax: (800) 442 - 5263
Web site: www.goindustries.com
E-mail: sales@goindustries.com

Trunk Trays

Installation Instructions

38306

Crown Vic '08

Parts List:

1 - Trunk Tray #38305-1	2 - 1/2" x 1 1/2" HH Bolts
1 - Left Side Slide #38305LS	2 - 1/2" Lock Washers
1 - Right Side Slide #38305RS	2 - 1/2" Hex Nuts
2 - Flat Bar Bracket #38306-3	4 - 1/2" Flat Washers
2 - Side Bracket #38305-2	12 - 1/4" Lock Nuts
2 - #8 x 1" Screw	12 - 1/4" x 3/4" HH Bolts
2 - Rubber Edging	

1. Remove the contents from the box and check for missing pieces or damage. If parts are missing or damaged, contact the original place of purchase. Read the instructions completely before beginning.

View of Driver Side Assembled Trunk Tray

Diagram 1

View of Driver Side Flat Bar Bracket #38306-3

Diagram 2

2. Assemble the tray as shown in **Diagram 1**. Make sure the tab on the slide is toward the front as shown in **Diagram 3**.

3. Place assembled tray into the trunk of the vehicle. Place (1) 1/2" x 1 1/2" HH bolt with a (1) 1/2" flat washer into the hinge area as shown in **Diagram 2** and place (1) 1/2" flat washer and (1) 1/2" hex nut onto the bolt then tighten. Repeat procedure for the other side of the vehicle. Level the tray and screw (1)#8 x 1" screw into the front of the tray as shown in **Diagram 3**. Repeat procedure for the other side of the vehicle.

View of Driver Side Slide

Diagram 3

Thank you for choosing Go Industries' products. For additional installation assistance, please call Technical Support (800) 352-4345 or (972) 783-7444