

Dually Mud Flap Set

Installation Instructions

725F

Chevy / GMC Dually

'73-'87

Contents:

- 1 pair of 725F (mud flaps)
- 1 Mud Flap kit

Place mud flap up to bracket. Align the three holes and use the mud flap kit to attach flap to bracket.

