

## Enforcement Series Lighted Grille Guard

Lightbar Assembly Instructions For:

**38XXXW2 - W5 / 38XXS2 - S5 / 38XXC2 - C5**

**39XXXW2 - W5 / 39XXS2 - S5 / 39XXC2 - C5**

**40XXXW2 - W5 / 40XXS2 - S5 / 40XXC2 - C5**

\*W Models designed for use with Whelen Ion lights ONLY\*  
 \*S Models designed for use with SoundOFF NForce lights ONLY\*  
 \*C Models designed for use with Code 3 MR6 lights ONLY\*

### **Note: Completely read instructions before beginning installation!**

1. Install your lights on to the light mount plate (using the light manufacturer's included hardware) so that they correspond with the openings in the light cover
2. Install the light mount plate onto the light shelf of the grill guard using (3) 10-24 x 3/8" bolts while allowing the electrical wiring to channel into the wiring passages along the grille guard uprights
3. Once all lights are secured, install the light cover using (5) 10 - 24 x 3/8" bolts to secure the cover to the grille guard
4. After all electrical wiring is terminated and run for your vehicle setup, you can install the wiring cover plates using the remaining (4) 10 - 24 x 3/8" bolts

